Bureau of Land Management, Interior

- (3) Weight and viscosity of mud that you will use in the uncemented portions:
- (4) Perforating or removing casing; and
 - (5) Restoring the surface; and
- (c) Any other information that we may require.

§ 3263.12 How will BLM review my Sundry Notice to abandon my well and notify me of their decision?

- (a) When BLM receives your Sundry Notice, we will make sure it is complete and review it for compliance with the requirements of §3200.4. We will notify you if we need more information or require additional procedures. If we need any further information to complete our review, we will contact you in writing and suspend our review until we receive the information. If we approve your Sundry Notice, we will send you an approved copy once our review is complete. Do not start abandonment of the well until we approve your Sundry Notice.
- (b) BLM may orally approve plugging procedures for a well requiring immediate action. If we do, you must submit the information required in §3263.11 within 48 hours after we give oral approval.

§ 3263.13 What must I do to restore the site?

You must remove all equipment and materials and restore the site according to the terms of your permit or other BLM approval.

§ 3263.14 May BLM require me to abandon a well?

If we determine that your well is no longer needed for geothermal resource production, injection, or monitoring, or if we determine that the well is not mechanically sound, BLM may order you to abandon the well. In either case, if you disagree you may explain to us why the well should not be abandoned. We will consider your reasons before we issue any final order.

§ 3263.15 May I abandon a producible well?

(a) You may abandon a producible well only after you receive BLM's approval. Before abandoning a producing

- well, send BLM the information listed in §3263.11. We may also require you to explain why you want to abandon the well.
- (b) BLM will deny your request if we determine that the well is needed:
- (1) To protect a Federal lease from drainage; or
- (2) To protect the environment or other resources of the United States.

Subpart 3264—Reports—Drilling Operations

§ 3264.10 What must I submit to BLM after I complete a well?

You must submit a Geothermal Well Completion Report, Form 3260-4, within 30 days after you complete a well. Your report must include the following:

- (a) A complete, chronological well history;
 - (b) A copy of all logs;
- (c) Copies of all directional surveys; and
- (d) Copies of all mechanical, flow, reservoir, and other test data.

§ 3264.11 What must I submit to BLM after I finish subsequent well operations?

- (a) Submit to BLM a subsequent well operations report within 30 days after completing operations. At a minimum, this report must include:
- (1) A complete, chronological history of the work done;
 - (2) A copy of all logs;
 - (3) Copies of all directional surveys;
- (4) The results of all sampling, tests, or surveys we require you to make (see § 3262.14);
- (4) Copies of all mechanical, flow, reservoir, and other test data; and
- (5) A statement of whether you achieved your goals. For example, if the well was acidized to increase production, state whether the production rate increased when you put the well back on line.
- (b) We may waive this reporting requirement for work we determine to be routine, such as cleanouts, surveys, or general maintenance. To request a waiver, contact BLM. If you do not receive a waiver, you must submit the report.